

vlangs vlan-id l3-interface

To associate a Layer 3 interface with a VLAN, use the **set vlangs vlan-id l3-interface** command. To remove the Layer 3 interface, use the **delete** form of the command.

Command Syntax

```
set vlangs vlan-id vlan-id l3-interface interface-name  
delete vlangs vlan-id vlan-id l3-interface
```

Parameters

<i>vlan-id</i>	VLAN identifier. The range of allowed VLAN identifiers is 1-4094. A range of VLAN identifiers can be used, for example, 2,3,4,5-100.
<i>interface-name</i>	Name of the Layer 3 interface.

Example

This example associates a Layer 3 interface vlan-1 with VLAN 10 and then removes the Layer 3 interface from the VLAN:

```
admin@Switch# set vlangs vlan-id 10 l3-interface vlan-1  
admin@Switch# commit  
admin@Switch# delete vlangs vlan-id 10 l3-interface  
admin@Switch# commit
```