

# Add a Port

To add a new port, click on **Port** from the menu on the left of the screen. Complete the port number, VLAN mode, tag, and trunks. Then, click **Add** to save it.

The screenshot shows the 'New Port' configuration form in a network management interface. The form is titled 'Configuration / br0 / Ports / New Port'. It contains the following fields:

- Port Number:** 1 (The port index that identifies the physical port on the switch.)
- VLAN Mode:** trunk (The VLAN mode of the port.)
- Tag:** 1 (The port's native VLAN.)
- Trunks:** 1000, 2000 (The VLAN or VLANs that this port trunks.)
- Flow Control:** none (Flow control is a mechanics allowing the receiving party of a connection to control the rate of the sending party.)

A red box highlights the 'Trunks' field, and a red arrow points to a callout box containing the following text:

8. Add trunk members as these,  
Eg. Add vlan1000 and vlan2000