

Add or Edit a Controller

PICAB Configuration Monitor Help Log Out

Switch Resource

- br0
- Basic Info
- Controllers**
- Ports
- Tunnels
- Link Aggregation
- Group Table
- Meter Table
- Flow Table
- Mirrors
- NetFlow
- sFlow

The following controllers are configured for this bridge.

Method	Connection Mode	IP Address	Port Number	Operations
tcp	out-of-band	10.10.50.47	6633	[Edit] [Delete]

Add a new controller

6. Add a new controller

7. Edit a exist controller