

run show filter copp

The **run show filter copp** command displays the configuration information of all CoPP policies, both pre-defined and user-defined, and match counter.

Command Syntax

run show filter copp

Parameter

None.

Example

- Show the configuration information of all CoPP policies, both pre-defined and user-defined, and match counter.

```
admin@Xorplus# run show filter copp
Filter:copp
  Description:
  Sequence: 10
    Description:
      match counter: 0 packets
    match-condition:
      protocol:          bpdu
    action: forward
    forwarding_class: bpdu-class
    .....
  Sequence: 81
  Description:
  match counter: 0 packets
  match-condition:
    destination-port: 23..23
    protocol:         tcp
  action: forward
  forwarding_class: copp-class3
  .....
  Input interface: inbound-control-plane
```