

show system management-ethernet

The **show system management-ethernet** command shows the configuration information, status and traffic statistics information of the management interface.

Command Syntax

show system management-ethernet [eth0 | eth1]

Parameter

None.

Example

- Run **run show system management-ethernet eth0** command to view the configuration information, status and traffic statistics information of the management interface.

```
admin@XorPlus# run show system management-ethernet eth0
eth0      Hwaddr: 00:18:23:30:e5:72      State: UP
          Gateway  : 192.168.10.1
          Inet addr:
              192.168.10.5/24
          Traffic statistics
          Input Packets.....3620
          Input Bytes.....462971
          Output Packets.....597
          Output Bytes.....75459
```