

# show system rollback compare to

---

The **show system rollback compare to** command shows the difference between two rolled back configurations.

## Command Syntax

run show system rollback compare to <other-config>

## Parameter

•<other-config>Show the difference between rolled back configuration [1-49] and current configuration.

## Example

• This example demonstrates how to show system rollback compare to 02:

```
admin@XorPlus# run show system rollback compare to 02
3c3
< /*Last commit      : Tue Apr 29 10:02:42 2014 by admin*/
---
> /*Last commit      : Tue Apr 29 09:38:47 2014 by admin*/
23c23
<           code-point 32
---
>           code-point 0
1254d1253
<   ntp-server-ip 192.168.10.100
```