

interface aggregate-ethernet <lag_name> snmp-trap

Users can enable or disable snmp trap when necessary.

Command Syntax

set interface aggregate-ethernet <lag_name> snmp-trap <bool>

delete interface aggregate-ethernet <lag_name> snmp-trap

Parameter

- <lag_name> Name of LAG interface.
- <bool> Snmp trap when port link up and down
 - **true** enable snmp-trap
 - **false** disable snmp-trap

Example

- This example enable snmp-trap for ae1:

```
admin@XorPlus# set interface aggregate-ethernet ae1 snmp-trap true
admin@XorPlus# commit
```