

set protocols ospf6 area virtual-link transmit-delay

User can configure the time to transmit an LSA on this address of the virtual link OSPF interface.

Command Syntax

set protocols ospf6 vrf <vrf-name> **area** <area-id> **virtual-link** <router-id> **transmit-delay** <time>

Parameter

- <vrf-name> Optional. Specifies a VRF name. The value is a string. It's a user-defined VRF set by the command **set ip vrf** <vrf-name> [description <string>].

Note that: The configuration is in the default VRF if not explicitly bound to any VRF.

- <area-id> The OSPF area to which the attached network belongs.
- <router-id> A unique 32-bit identifier within this AS.
- <time> The extra addition to age field of all transmitted LSAs range 0-3600.

Example

- This example configure the time 2 seconds to transmit an LSA on this address of the virtual link OSPF interface.

```
admin@XorPlus# set protocols ospf6 area 0.0.0.0 virtual-link 4.4.4.4 transmit-delay 2
admin@XorPlus# commit
```