

# set protocols ospf6 area virtual-link retransmit-interval

---

User can configure the interval time of virtual link OSPF interface retransmitting the OSPF route.

## Command Syntax

**set protocols ospf6 vrf** <vrf-name> **area** <area-id> **virtual-link** <router-id> **retransmit-interval** <time>

## Parameter

- <vrf-name> Optional. Specifies a VRF name. The value is a string. It's a user-defined VRF set by the command **set ip vrf** <vrf-name> [description <string>].

Note that: The configuration is in the default VRF if not explicitly bound to any VRF.

- <area-id> The OSPF area to which the attached network belongs.
- <router-id> A unique 32-bit identifier within this AS.
- <time> The retransmit interval range 1-65535.

## Example

- This example configures the interval time 20 seconds of virtual link OSPF interface retransmitting the OSPF route

```
admin@XorPlus# set protocols ospf6 area 0.0.0.0 virtual-link 4.4.4.4 retransmit-interval 20
admin@XorPlus# commit
```