

interface aggregate-ethernet <lag_name> storm-control <mode> pps

Users can set storm control mode for a specified port.

Command Syntax

set interface aggregate-ethernet <lag_name> storm-control <mode> pps <value>
delete interface aggregate-ethernet <lag_name> storm-control broadcast pps

Parameter

- <lag_name> Name of LAG interface.
- <mode> packets forwarding mode
 - **broadcast** Storm control for broadcast traffic
 - **multicast** Storm control for multicast traffic
 - **unicast** Storm control for unicast traffic
- <value> Packets per second, [0..30000000]

Example

- This example set broadcast storm control for ae1:

```
admin@XorPlus# set interface aggregate-ethernet ae1 storm-control broadcast pps 1000
admin@XorPlus# commit
```