

# interface aggregate-balancing hash-mapping field ethernet-destination-address disable

---

This command designates data packets to be forwarded via the ethernet-destination-address.

## Command Syntax

Set interface aggregate-balancing hash-mapping field ethernet-destination-address disable **<true /false>**

To remove the configuration enter:

delete interface aggregate-balancing hash-mapping field ethernet-destination-address disable

## Parameter

- **true**--disable ethernet-destination-address
- **false**--enable ethernet-destination-address

## Example

This example enables data packets forwarded by ethernet-destination-address:

```
admin@XorPlus# set interface aggregate-balancing hash-mapping field ethernet-destination-address disable false
admin@XorPlus# commit
```