

vlan-interface loopback address <ip-address> prefix-length

User can configure one or more address for the vlan interface.

Command Syntax

set vlan-interface loopback address <ip-address> prefix-length <int>
delete vlan-interface loopback address <ip-address>

Parameter

- <ip-address> Ipv4 or Ipv6 address.
 - Ipv4 default value: 127.0.0.1
 - Ipv6 default value: ::1
- <int> the ipv4 network prefix length is 32.
the ipv6 network prefix length is 128

Example

- This example configure the lookback ipv4 and ipv6 address :

```
admin@XorPlus# set vlan-interface loopback address 202.115.114.2 prefix-length 32
admin@XorPlus# set vlan-interface loopback address 2201:00:: prefix-length 128
admin@XorPlus# commit
admin@XorPlus# delete vlan-interface loopback address 202.115.114.2
admin@XorPlus# delete vlan-interface loopback address 2201:00::
admin@XorPlus# commit
```