

set firewall filter sequence log interval

To configure the log interval for a filter sequence, use the **set firewall filter sequence log interval** in L2/L3 configuration mode. To remove the log interval, use the **delete** form of the command.

Command Syntax

set firewall filter *filter-name* **sequence** *number* **log interval** *time*
delete firewall filter *filter-name* **sequence** *number* **log interval**

Parameters

<i>filter-name</i>	Filter name
<i>number</i>	Sequence number. The range is 0-9999.
<i>time</i>	Log interval in seconds.

Example

The following example configures sequence 10 of the *MyFilter* filter to record the log every 15 seconds:

```
admin@Switch# set firewall filter MyFilter sequence 10 log interval 15
```

The following example removes the log interval from sequence 10 of *the MyFilter* filter:

```
admin@Switch# delete firewall filter MyFilter sequence 10 log interval
Deleting:
> interval: 15
OK
```