

# set vxlans ovldb-managed

User can configure enable vxlan ovldb managed.

## Command Syntax

set vxlans ovldb-managed *<boolean>*

delete vxlans ovldb-managed

## Parameter

• *<boolean>* enable or disable vxlan ovldb managed.

- **true** enable vxlan ovldb managed
- **false** disable vxlan ovldb managed

## Example

• This example demonstrates how to configure enable vxlan ovldb managed.

```
admin@XorPlus# set vxlans ovldb-managed true
admin@XorPlus# commit
```