

system syslog port-protocol

User can configure the syslog host port transport protocol. The protocol can be tcp or udp. User can also delete the configuration.

Command Syntax

```
set system syslog port-protocol <trans-protocol>  
delete system syslog port-protocol
```

Parameter

•<trans-protocol> Configure transport protocol. Required select include:

- **tcp** tcp syslog transmission
- **udp** udp syslog transmission



It is recommended to configure **UDP** protocol as the port protocol.

Example

• This example demonstrates how to set the syslog host transport protocol as tcp:

```
admin@XorPlus# set system syslog port-protocol udp  
admin@XorPlus# commit
```