

set protocols ospf4 area virtual-link transmit-delay

User can configure the time to transmit an LSA on this address of the virtual link OSPF interface.

Command Syntax

set protocols ospf4 vrf *<vrf-name>* **area** *<area-id>* **virtual-link** *<router-id>* **transmit-delay** *<time>*

Parameter

- *<vrf-name>* Optional. Specifies a VRF name. The value is a string. It's a user-defined VRF set by the command **set ip vrf** *<vrf-name>* [**description** *<string>*].

Note that: The configuration is in the default VRF if not explicitly bound to any VRF.

- *<area-id>* The OSPF area to which the attached network belongs.
- *<router-id>* A unique 32-bit identifier within this AS.
- *<time>* The extra addition to age field of all transmitted LSAs range 1-3600.

Example

- This example configure the time 2 seconds to transmit an LSA on this address of the virtual link OSPF interface.

```
admin@XorPlus# set protocols ospf4 area 0.0.0.0 virtual-link 4.4.4.4 transmit-delay 2
admin@XorPlus# commit
```