


interface aggregate-ethernet <lag_name> aggregated-ether-options flow-control

Configure flow-control for a logical port.

 On N1148T-ON platform, flow control in the inbound direction of the interface is not supported.

Command Syntax

set interface aggregate-ethernet <lag_name> aggregated-ether-options flow-control <true /false>

To return the configuration enter:

delete interface aggregate-ethernet <lag_name> aggregated-ether-options flow-control

Parameter

- *<lag_name>*--Enter the name of the configured LAG interface.
- true: enable flow control
- false: disable flow control

Example

This example enables flow-control on the LAG ae1:

```
admin@XorPlus# set interface aggregate-ethernet ae1 aggregated-ether-options flow-control true
admin@XorPlus# commit
```