

# Layer 3 Unicast Routing Commands

- `run show arp`
- `run show neighbors`
- `run show route`
- `run show route forward-host`
- `run show route forward-route`
- `run show vrf`
- `set ip vrf`
- `set ip routing enable`
- `set system management-vrf enable`