

interface gigabit-ethernet <port> wred queue <value> ecn_thresh

Users can set ecn_thresh.

Command Syntax

```
set interface gigabit-ethernet <port> wred queue <value> ecn_thresh <int>
delete interface gigabit-ethernet <port> wred queue 2 ecn_thresh
```

Parameter

- <port> ethernet switching port identifier, the valid ports range 1-52
- <value> The queue number, [0..7]
- <int> The threshold identifier, [0..1], 0 stands for disable ecn, 1 stands for enable ecn.

Example

- This example sets ecn_thresh for ge-1/1/3:

```
admin@XorPlus# set interface gigabit-ethernet ge-1/1/3 wred queue 2 ecn_thresh 0
admin@XorPlus# commit
```