

Displaying the Debugging Message

User can configure the debugging message in a current window.

Syslog Monitor On

```
admin@XorPlus> syslog monitor on
Nov 21 2000 22:27:39 XorPlus local0.warn : [SIF]Interface ge-1/1/3, changed state to up
Nov 21 2000 22:27:41 XorPlus local0.warn : root logged the switch
Nov 21 2000 22:41:18 XorPlus local0.info xinetd[1102]: START: telnet pid=7650 from=10.10.50.16
Nov 21 2000 22:41:23 XorPlus authpriv.debug login[7651]: pam_unix(login:account): account admin has password
changed in future
Nov 21 2000 22:41:26 XorPlus local0.warn : admin logged the switch
Nov 21 2000 22:55:58 XorPlus local0.info xinetd[1102]: START: telnet pid=8039 from=10.10.51.16
Nov 21 2000 22:56:01 XorPlus authpriv.debug login[8040]: pam_unix(login:account): account root has password
changed in future
Nov 21 2000 23:31:13 XorPlus local0.info xinetd[1102]: START: telnet pid=9028 from=10.10.50.16
Nov 21 2000 23:31:16 XorPlus authpriv.debug login[9029]: pam_unix(login:account): account admin has password
changed in future
Nov 21 2000 23:31:21 XorPlus local0.warn : admin logged the switch
admin@XorPlus>
```