

# interface gigabit-ethernet <port> wred queue <value> enable

---

Users can set wred queue when necessary.

## Command Syntax

```
set interface gigabit-ethernet <port> wred queue <value> enable <bool>
delete interface gigabit-ethernet <port> wred queue <value> enable
```

## Parameter

- <port>: ethernet switching port identifier, the valid ports range 1-52
- <value>: The queue number, [0..7]
- <bool>: Set enable

- **true** enable wred
- **false** disable wred

## Example

- This example sets wred queue for ge-1/1/3:

```
admin@XorPlus# set interface gigabit-ethernet ge-1/1/3 wred queue 2 enable true
admin@XorPlus# commit
```