

interface aggregate-ethernet <lag_name> disable

Enable or disable a logical interface.

Command Syntax

set interface aggregate-ethernet <lag_name> disable <true | false>

To delete the configuration enter:

delete interface aggregate-ethernet <lag_name> disable

Parameter

- <lag_name> Name of LAG interface.
- true: disable a logical interface
- false: enable a logical interface

Example

This example disables the ae1 interface:

```
admin@XorPlus# set interface aggregate-ethernet ae1 disable true
admin@XorPlus# commit
```