

# set firewall filter copp sequence from ether-type

The **set firewall filter copp sequence from ether-type** command configures a firewall filter rule based on the Ether-Type values for traffic classification.

## Command Syntax

**set firewall filter copp sequence** *<number>* **from ether-type** *<ether-type>*

## Parameter

Parameter	Description
<b>sequence</b> <i>&lt;number&gt;</i>	Specifies filter sequence number. The value is an integer that ranges from 0 to 9999.  The 15 integers 10, 20, 30, 40, 50, 60, 70, 80, 90, 100, 110, 120, 130, 140, 150 are not allowed to be used for sequence numbers in user-defined CoPP firewall filter rules.
<b>ether-type</b> <i>&lt;ether-type&gt;</i>	Specifies an Ether-Type value. The value is an integer in decimal format that ranges from 1501 to 65535.

## Usage Guidelines

You can run the **set firewall filter copp sequence from ether-type** command to configure a firewall filter rule based on the Ether-Type for traffic classification so that the device processes packets matching the same firewall filter rule in the same manner.

## Example

- Configure a firewall filter rule based on the Ether-Type value 34525.

```
admin@XorPlus# set firewall filter copp sequence 51 from ether-type 34525
admin@XorPlus# commit
```