

vxlan vni <text> interface

User can configure the interface permitted to pass through the vxlan tunnel. This interface should be assigned in the host side. All packets entering this interface can be transmitted in the vxlan, no matter the tagged or untagged packet.

Command Syntax

```
set vxlan vni <text> interface <port>
```

```
delete vxlan vni <text> interface <port>
```

Parameter

- <text> VXLAN segment ID, decimal format ranges 1-16777215 or notation dotted format 100.100.200
- <port> port identifier, the valid ports range 1-52.

Example

- This example demonstrates how to configure the interface te-1/1/29 add to vxlan VNI 10010

```
XorPlus# set vxlan vni 10010 interface te-1/1/29
XorPlus# commit
```